

Loading SNMP MIBs

From the Silver Peak website, you can download a [.zip file](#) of the Standard and the Silver Peak proprietary MIBs (Management Information Base) files, for loading into whatever MIBs browser you're using.

- You can choose to install the Standard MIBs, the Silver Peak proprietary MIBs, or both.
- Because there are dependencies, you must load the files in a specific sequence. Refer to README.TXT in the .zip file for instructions.
- The Standard list and the Silver Peak list share the same first three files. If you choose to load both the Standard and the Silver Peak MIBs, load either list completely and then append the non-common files from the remaining list.